



13041306




Liste de pièces Lista de Piezas Parts List







<u>No.</u>	Part No.	<u>Description</u>
1	68001128	ARM SHAFT BUSING
2	68001133	HAND WHEEL
3	68001130	MOTOR DRIVE BELT (250×500×5)
#1	68001134	THREAD TAKE UP LEVER COMPLETE




No.	Part No.	Description
4	00004405	
1	68001135	PRESSER BAR LIFTER LEVER
2	416118401	SHANK SCREW (9/64×40×8)
3	416495501	SHANK COMPLETE
4	416128401	ALL PURPOSE FOOT
5	68001138	THREAD GUIDE
#1	416245301	NEEDLE CLAMP COMPLETE
# I	410245301	NEEDLE CLAMP COMPLETE




No.	Part No.	Description
1	68001139	REVERSE LEVER BUTTON
#1	68001140	PATTERN CAM CONTACT




No.	Part No.	<u>Description</u>
#1	68001141	DIAL TENSION SUPPORTER PLATE COMPLETE
#2	68001142	MOVEMENT PLATE SUPPORTER




No.	Part No.	Description
1	68000174	SHUTTLE DRIVER COMPLETE
2	416392101	SHUTTLE HOOK
3	68000175	BOBBIN
4	416171501	NEEDLE PLATE
#1	68000176	OPEN SHUTTLE RACE COMPLETE
#2	416153401	BOBBIN CASE COMPLETE
#3	416245801	LOWER SHAFT GEAR COMPLETE



No.	Part No.	<u>Description</u>
1	68001145	SWITCH RECEPTACLE ASSY (230V)
2	416521701	SWITCH ASS' Y
3	68001147	FOOT CONTROLLER (230V)
4	68001146	LED HOLDER
5	68001144	MOTOR (FOR 230V)
6	68001143	MOTOR (FOR 120V)




No.	Part No.	Description
1	416515001	SPOOL PIN PLATE
#1	68001148	BOOBIN WINDER COMPLETE



No.	Part No.	Description
1	68001149	PATTERN SELECTOR DIAL (FOR 1304)
	68001150	PATTERN SELECTOR DIAL (FOR 1306)





No.	Part No.	Description
1	416128401	ALL PURPOSE FOOT
2	416128701	ZIPPER FOOT (I)
3	416128901	BUTTONHOLE FOOT (B)
4	416127901	FELT PAD
5	68000177	L-SCREWDRIVER
6	416127701	SEAM RIPPER/ BRUSH
7	416127301	SPOOL PIN FELT
8	68000175	BOBBIN
9	68001151	SOFT COVER