


SINGER
328K

List of Parts—Machine No. 328K



ATTACHMENT SET 161615

- | | |
|------------|----------------------|
| 32773 | Presser Foot |
| 86742 | Ruffler |
| 81245 | Binder |
| 161172 | Seam Guide |
| 161294 | Screwdriver (LG) |
| 161295 | Screwdriver (SM) |
| 161609 | Tube of Oil |
| 161611 | Attachment Box |
| 161613 | Button Foot |
| 161614 | Throat Plate |
| 161671 | Hemmer Foot |
| 161771 | Applique Foot |
| 161894 | Raising Plate |
| 172336 | Bobbin (Plastic) (4) |
| 276302 | Fashion Disc 2 |
| 276303 | Fashion Disc 3 |
| 276305 | Fashion Disc 5 |
| 276306 | Fashion Disc 6 |
| 276309 | Fashion Disc 9 |
| 276310 | Fashion Disc 10 |
| 276313 | Fashion Disc 13 |
| 276331 | Fashion Disc 31 |
| 2020(15x1) | Needles 14 (3) |



List of Parts—Machine No. 328K

